



Shelbourne Header Monitor Wiring diagram

Item 1 RDS-0010 No Longer Available subs up to RDS-0027

Item 2 RDS-0011 Tacho Head Plug and Arms

Item 3 RDS-0012 Harting Connector & Sticker

Item 4 RDS-0013 External Alarm

Item 5 RDS-0014 Power Lead

Item 6 FUS-0022 Fuse 2 Amp

Item 7 RDS-0015 Combine Lead

Item 8 RDS-0016 24V – 12V Converter Kit

Item 10 RDS-0017 Header Lead

Item 11 RDS-0018 Shaft Sensor

Item 12 RDS-0019 Magnet

Item 13 RDS-0020 Magnet & Carrier

Item 14 RDS-0021 Rotor Sensor Bracket

Item 15 RDS-0027 Tacho Head

Item 15a RDS-0029 Tacho Head Fixing Kit

Item 16 RDS-0006 Connector Lead

Item 17 RDS-0028 Junction Box/Combine Lead

Item 17a FUS-00026 Fuse 15 Amp

